

Dodge Ram 2500 14S-18S-24S



Figure 1

Tools Needed:

Torch or cutoff wheel to remove old muffler. - Pry Bar - WD40 - Air Impact gun with 9/16 socket

Begin removing old muffler

Spray rubber hangers with WD40 and "pop" them off with a pry bar

If, you have a torch, burn old clamps off and heat neck of outlet side of muffler to remove tailpipe, then heat inlet side and remove muffler from truck.

Install new muffler with long inlet tube facing the front of the truck.

Install hangers as seen in photo.

Re install tailpipe [do not tighten clamps until all components are aligned properly]

[Make sure the tailpipe clamps are at the very edge of the muffler outlet or they will not compress onto the tailpipe]

