

LS1HR Installation Instructions

[Install instructions with simple hand tools for the LS1HR]



Figure 1



Figure 2



Figure 3

First, Remove the 10mm nut from the heat shield stud and pull the heat shield off the stud.

Then slide the upper hanger on the exposed stud and re-install the heat shield and the 10mm nut [DO NOT TIGHTEN THE NUT YET]

Open up the 3" clamp on the lower bracket and slide it over the Y pipe and re-install the washer and nut.

Slide the rubber hangers on the studs of both the upper and lower hangers and set pre-load as desired by rotating the lower clamp up into the rubber hanger. Tighten the upper hanger, then tighten the lower hanger clamp on the Y pipe.

Test drive the car and if the Y pipe is still hitting the underside of the car on the drivers side, rotate the lower clamp counter clockwise [looking from the back of the car] to pre-load the hanger until the desired effect has been reached.