

2019 & Newer Ram 1500 Installation Instructions

Tools needed

½" drive Impact gun with 15mm socket, 16 mm socket and 9/16 socket and 9/16 wrench

WD40 type spray lubricant

Pry bar

Sawzall with metal cutting blade.

Begin by cutting pipe rear of muffler at desired point 1" from weld (Fig 1)



Figure 1

Proceed then to "pop" steel hangers out of orange rubbers Fig 2 (wd 40 helps in disassembly)



Figure 2

After removing hangers, remove bolts at muffler flange (16mm) and then remove stock muffler from truck



Figure 3

Apply High temp silicone sealer(supplied) into outlet of Mufflex Kit (fig 3).Install Mufflex exhaust by sliding exhaust stub with 2 bolt flange and front clamp/hanger into muffler kit Fig 4.



Figure4

Install rear hanger bracket into orange tailpipe hangers and on to existing tailpipe, and then



Figure5

Slide Mufflex exhaust kit onto factory tailpipe (note muffler is slightly canted sideways see photo) Figure 5

Align Mufflex 2 bolt flange with Dodge flange with supplied bolts (re use Dodge gasket) and bolt together (check tailpipe/tip alignment with bumper at this time). Begin tightening (with $\frac{1}{2}$ " drive impact gun) hardware from front to back.

