

93401CDT Installation Diagram

Diagram for 93401CDT
93401CDT Clamp/Hanger Location



Figure 1



Figure 2

- (2) 4 Inch Easy-clamps connect exhaust pipes together
- (1) 4 Inch Accu-seal Clamp Connects the Over-axle Pipe to the Muffler
- (2) 3 Inch Accu-seal Clamps Connect the Tailpipe to the SS Tip
- (2) 3 Inch SS Hose Type Clamps Connect the SS Tips to the Rear Tailpipe Hangers
- (1) 3 Inch Muffler Clamp Attaches the L Bracket Assembly to the Drivers Side Tailpipe.
- (2) Short Hangers Attach to the Bumper Support Studs. [Nuts come off with a 13mm Socket]

NOTE It May be Necessary to Push up the Heat Shield at the Over-Axle Pipe for Additional Clearance