

# DODJP Installation Diagram

Diagram for DODJP



Figure 1



Figure 2

Tools Needed:

**Sawzall – Air Impact Gun w/15MM Socket – WD-40 – Pry Bar**

With marker make cut marks at 4.5" and 7.5" forward of hanger that support's the inlet of muffler. Make First Cut 4.5" and then second cut to leave a 3" gap for DODJP

(SEE PHOTO).

Slide 3" clamps onto pipes. (it is recommended that you use high temp silicone sealer as an assembly paste for an air tight seal). WD-40 all rubber hangers and pry exhaust towards the rear of the vehicle, enough to slip 3" tube in-line with the 90 degree tube facing the front of the truck

(SEE PHOTO).

Slide 2.5" clamp onto 90 degree pipe and install 180 degree tube. Push tube all the way into the expansion for now. Tighten all clamps.

If all resonance is not gone loosen 2.5" clamp and begin pulling tube out 1" at a time. (THERE MUST BE A MINIMUM OF 2" OVERLAP FOR EXHAUST TO SEAL)

**\*Note: All Clamps must be at the very edge of the pipe to ensure complete exhaust seal**

