

DODTP5 Tips Installation Diagram

DOD TP5 Installation Diagram



Figure 1



Figure 2

Tools Needed for Install; 13-mm Socket w/Ratchet.

A vice or channel lock pliers - WD-40 type spray. -

The work can be done without lift or ramps [But, they are helpful.]

Spray WD-40 on factory tip clamp bolts and loosen the 13 mm bolts until tips become loose enough to wiggle off the tailpipes. Then remove from truck..

Put the clamp on Mufflex tip and re-install on factory tailpipe.

Leave bolts snug until adjustments have been made.

Then tighten the tip bolts until the tips are secure.

