

2014 + Dodge Ram 2500/3500 6.4L Mufflex

DOD250035 / DOD250035MD / DOD250035L install instructions

Tools needed:

Impact gun with 15mm and 9/16 socket's

Rubber mallet

WD 40 type lubricant

Pry bar

Begin by spraying rubber mounts with WD40 and remove from truck with pry bar

With 15 mm socket loosen tailpipe clamp and remove tailpipe. (Clamp stays on tailpipe)

Loosen muffler clamp and remove muffler

Slide 3.5" inlet clamp onto exhaust pipe then Install Mufflex exhaust onto exhaust pipe and support rear of kit with hanger provided (hanger has two rods on it)
Rods point forward towards the front of the truck (this hanger is used to support pipe only it does not replace tailpipe clamp)

Re install tailpipe onto Mufflex exhaust kit and put rubber mounts back on.

Install inlet clamp onto rubber mount.

Check tailpipe alignment and begin tightening clamps from front to back (make sure pipes are bottomed out into each other before tightening)