

Durango 2011 5.7 Hemi Truck Installation Instructions

Below is a list of Mufflex supplied parts:

[1] Rear Muffler bypass kit.

[1] Gasket.

[1] 2.25" Band Clamp.

[2] Nuts and Bolts.

Required tools to complete installation.

[1] Sawz-all with metal cutting blade

[1] 15mm socket [with air gun or ratchet]

[1] WD-40 spray [recommended]

Driver side bypass: Spray nuts at muffler flange and rubber hanger mount to muffler with WD 40

Remove nuts off of muffler flange with 15mm socket and remove muffler from vehicle [FIGURE 1]



Figure 1

Install RMB with new gasket and nuts & bolts provided & snug up bolts

[But do not tighten yet!] Make sure tip is centered in bumper bezel.

Passenger side Bypass: Spray Rubber hanger with WD 40. With marker or, pencil make a mark 2" behind weld on exhaust pipe hanger. [FIGURE 2 & FIGURE 3]



Figure 2



Figure 3

Cut tube with sawz-all and remove the muffler. Install Passenger side bypass by slipping inlet over cut part of tube. [Put 2.25" on pipe first] and snug up clamp [Do Not Tighten up yet!]

Go to back of vehicle and check alignment of tips, making sure the length sticking out of the bumper is the same and tighten the driver's side first.

Please re-check the alignment again because the gasket will crush a bit and then tighten the passenger's side.

If you should have any questions concerning this install, or any Mufflex related issues, you can contact our support team at questions@mufflex-performance.com